

CS9900 Navigation Box Connectors Pinout

24-pin and 20-pin connector pinout:


FRONTEND Connect Pin define(24pin)

1.ACC	2.BATTER
3.GND_D	4.GND_D
5.Touching control TX (EXT1)	6.VOUT_R
7.Touching control RX (EXT2)	8.GND_D
9.Navi Mute (EXT3)	10.VOUT_B
11.Rear Camera trigger (EXT4)	12.GND_D
13.VCC_EXTSWDC	14.VOUT_G
15.SPEAK_OUTL	16.GND_D
17.SPEAK_OUTR	18.CSYNC
19.GND_D	20.GND_D
21.HPOUT_R	22.MIC_IN

REAR Connect Pin define(20pin)

1.GND_D	2.Line_IN_L
3.Camera	4.Line_IN_R
5.AV_IN	6.GND_D
7.GND_D	8.UART1_TX
9.USB1_DP	10.UART1_RX
11.USB1_DM	12.VCC_M5V_OUT
13.DVBUS	14.UART2_TX
15.USB2_DP	16.UART2_RX
17.USB2_DM	18.IR_IN

4-pin touch pinout:



H sync, Y sync pinout:

