

## Car AUX Adapter for Toyota


### User and Installation Manual

#### Head Unit LCD Displaying

1. CD: pre-set single /6 disc
2. MD: AUX Input

#### Operation:

1. Press CD (or DISC ) button then select :
  - 1) CD preset 6 or single disc
  - 2) MD: ^DISC~1→AUX1  
2→AUX2
2. Under any mode, head unit can be trigger to AUX2 by REM3~15V (orange wire) .
3. Before AUX2 is moved off , head unit may still select other devices directly.  
And if to trigger AUX2 again, REM orange wire must be released first and then trigger again.



- \*\*\* There are various kinds of Toyota radio unit with various function.  
Brown loop wires allows the alternative option in case the connection doesn't function normal.
- Steps to switch the brown loop wires:
- 1- Parking shift
  - 2- ACC OFF
  - 3- Switch brown loop wires connection (connect or disconnect)
  - 4- ACC ON then TEST