


R05-AUDI TT Rear View Camera Interface

Version Information


Model Name	R05-AUDI TT
Latest Firmware Date	13.Apr.2016
Manual Version	Rev. 2.1
Manual Release Date	13.Apr.2016

DIP Switch Settings




No.1	Rear View CAM	ON(▼) / OFF(▲)
No.2	Front View CAM	ON(▼) / OFF(▲)
No.3	N.C	
No.4	N.C	
No.5	Parking Line type	ON(▼) Same as A3 / OFF(▲) New One
No.6	Parking Line ON / OFF	ON(▼) / OFF(▲)

Components



Mode Change for AUDI TT



Buttons	Function
NAVI/MAP	Change the mode to FVC(AV1) (press the button 2 seconds)

Enter Setting menu




* Connect **MON / PAS CAN**

R05-AUDI TT Rear View Camera Interface

Installation Diagram

Head Unit(in the glovebox) – Main connector



CAN wires Information

