



## 2015 IM22B – BENZ 2015 [NTG5.0/ 5.1] 8" Monitor Integration Video Interface (FPG&PDC)

1) Compatible with : 2015 E. B. CLA. CLS. A-CLASS

### 2) How to switch the screen



- 1 It will switch the screen when you press **OK** 2 seconds (Original->NAVI->AV1->AV2->AV3->MIRRORING)
- 2 Press the button for 2 seconds (direct to AV1)
- 3 Press the button for 2 seconds (direct to AV2)
- 4 Press the button for 2 seconds (direct to AV3)
- 5 Press the button for 2 seconds (direct to mirroring)

### 2-1) How to link original jog shuttle



- ※ It will have reaction when you connected IR line of the navigation.
- ※ It will not do the movement when the function out of navigation.

- 1 Switch the screen(Press for 2 seconds) [Original->NAVI->AV1->AV2->AV3->MIRRORING]
- 2 Direct to Original (Press for short)
- 3 Left key of the navigation, and it also can switch the DMB channel (Press for short)
- 4 Right key of the navigation, and it also can switch the DMB channel (Press for short)
- 5 Up key of the navigation (Press for short)
- 6 Down key of the navigation (Press for short)
- 7 OK key (Press for short)
- 8 Direct to DMB of the navigation (Press for 2 seconds)
- 9 Direct to Our home of the navigation (Press for 2 seconds)
- 10 Direct to Company of the navigation (Press for 2 seconds)

### 2-2) How to set by original jog shuttle

- 6 Direct to setting menu (Press for 7 seconds) the cursor moves to the left side (Press for short)
- 7 the cursor moves to the left side (Press for short)
- 8 the cursor moves to the left side (Press for short)
- 9 the cursor moves to the left side (Press for short)
- 10 the cursor moves to the left side (Press for short)
- 11 Menu selection (Press for short)
- 6 Submenu (Press for short)

- ※ After finishing setting on the submenu, select exit to quit.
- ※ Setting by R/C is possible.


※ How to set DIP S/W ※

ON	ON	OFF	OFF	DIP_SW1 : X
OFF	OFF	OFF	OFF	DIP_SW2 : X
ON	ON	ON	ON	DIP_SW3 : X
OFF	OFF	OFF	OFF	DIP_SW4 : X

ON	ON	OFF	OFF	1.1.1.1 :
OFF	OFF	OFF	OFF	E. B. CLA. CLS. A-CLASS
ON	ON	ON	ON	1.1.0.0 :
OFF	OFF	OFF	OFF	C-CLASS 8.4"
ON	ON	OFF	OFF	1.1.1.0 :
OFF	OFF	OFF	OFF	C-CLASS 7"

### 3) How to connect can



support@car-solutions.com

### 4) How to set R/C



Press **OK** button 4time than you will see the number **1** on the left top of the screen from 1~4, when it's number 4, press the **OK** button to enter the setting mode.



[ Components ]

Main cable, 4PIN film, Main Unit, RGB cable, HDMI cable, RCA cable, AV gender, DIGITAL RGB gender, R/C, Original LVDS extension gender, Original POWER extension gender.

\*Separate purchasing (W205 C-class)

[W205 C-class (Mercedes)]

www.car-solutions.com