




2017년
Plug and Play

NEW BMW 3 EVO(SP25F)


BMW - 2, 3, 4, X3, X4 SERIES VIDEO FPG&PDC INTERFACE

DOC NO : 17/01/16

1) HOW TO SET T S/W MODE [(ON,DOWN) 0 : ↓ off / (OFF,UP) 1 : ↑ off]



- DIP_SW1 : Navigation On/Off
- DIP_SW2 :
- DIP_SW3 :
- DIP_SW4 : REAR VIEW On/Off
- DIP_SW5 :
- DIP_SW6 :
- DIP_SW7 : On
- DIP_SW8 : On



* PLEASE SET AV 1,2,3 FRONT CAMERA ON/OFF ON OSD MENU.

2) HOW TO SWITCH SCREEN



- 1 PRESS MENU BUTTON FOR 2S
- 2 PRESS MAP BUTTON FOR SHORT

2016

NEW X3, X4, 2, 3, 4 SERIES 8.8" MONITOR

*MODE CHANGE FOR AC [PRESS Δ BUTTON (12 O' CLOCK DIRECTION)]



[ORIGINAL] [AV]



[AV] [ORIGINAL]



[AV FULL]

3) HOW TO SWITCH THE REAR VIEW CAMERA (PLEASE REVERSE GEAR FOR SETTING)

REAR VIEW SCREEN SIZE, PIP POSITION

PRESS Δ FOR LONG TO CHANGE SCREEN SIZE OF REAR VIEW



2016

NEW X3, X4, 2, 3, 4 SERIES 8.8" MONITOR



4) ORIGINAL BUTTON FUNCTIONS




- 1 PRESS MENU BUTTON FOR 2SEC TO CHANGE MODE
- 2 PRESS MAP BUTTON FOR SHORT TO CHANGE MODE
- 3
- 4
- 5 FOR KOREAN DIGITAL NAVI ONLY
- 6 FOR KOREAN NAVI CONTROL
- 7
- 8 BACK BUTTON : OK


* GOING TO AV INPUT DIRECTLY



* COMPONENTS



Plug and Play



5) HOW TO ENTER GPS SETTING MODE



PRESS OK BUTTON 4 TIMES THEN YOU WILL SEE THE NUMBER 1 ON THE LEFT TOP OF THE SCREEN FROM 1~4. WHEN IT'S NUMBER 4, PRESS THE OK BUTTON TO ENTER THE SETTING MODE.