

How to use Buttons

LC 200



-- HOME

Press	Mode	Function
Short Press	ROIK	To OEM Screen




-- AUDIO

Press	Mode	Function
Short Press	ROIK	To OEM Screen




-- INFO

Press	Mode	Function
Short Press	ROIK	To OEM Screen



-- PHONE

Press	Mode	Function
Short Press	ROIK	To OEM Screen



-- NAV

Press	Mode	Function
Short Press	ROIK	To OEM Screen
Long Press	OEM	To ROIK Screen



-- SETUP

Press	Mode	Function
Short Press	ROIK	To OEM Screen