

QCAST2 Mirroring Adapter User Manual



1. Exterior and components



Mainboard



Powercable



Mode button



Antenna




HDMI cable


2. Specification

Section	Description
Product name	QCAST2
OS	Linux
Wi-Fi	Dual band Wi-Fi 2.4G/5G
Video Output	HDMI (1280x720xP60)
GPIO	Mirroring Mode Change
Power	DC 12V / 0.5A
Dimension	130mm(W) x80mm(H) x 25mm(D)
Operating Temperature	-20°C ~ +70°C

3. Installation



Android Mirroring



1. After power is supplied to Qcast2, Android mirroring mode will appear
2. Settings → Choose “Screen Mirroring or Screen Viewer”
3. Choose Device name ex) Qcast-xxxx
4. Connection completed after few seconds
5. Press “Screen Mirroring or Screen Viewer” to disconnect the mirroring

iOS Mirroring



1. Press the mode button to switch the mirroring mode from Android to iOS
2. Wait for a moment to display the following message
 “Status: Waiting for connection”
3. Settings → Wi-Fi → “Choose device name ex) Qcast-xxxx
 (PW:12345678)
4. Drag iPhone’s screen from bottom to top and touch on “AirPlay”
5. Select the same device name from step 2 and set mirroring “ON”
6. If Wi-Fi or Airplay is disconnected, the mirroring will stop