

User Manual

for **LEXUS**





Android Auto Apple CarPlay



Specifications



Specification

Input	USB/CVBS signal input	
Input Voltage	12-16V DC	
Rated Current	2A	
Rated Power	24W	
Control	Steering wheel control, iDrive control	
Materiaport@car-solutionବୁତ୍ୟମନ୍ତ aluminum		

Panel description

CAN	For power cable connection, CAN data transmission	
USB/Video	USB data transmission, and for reverse/front camera conenction	
HDMIIN	HDMI input, support up to 720P	
LVDS	Connect with LVDS cable we provided	
RF Cable	Wifi antenna connector	
Toggle switch	Refer DIP code setting to set for different screen size	

Features

- >Support wireless/wired Carplay connection
- >Support wireless/wired Android auto function (some mobile phones)
- >Support wireless Airplay function
- >Support wired Autolink function
- >Compatible with OEM microphone and external microphone
- >Support EQ adjustment, lossless sound quality
- >Support HDMI input
- >Support USB to play audio file &video, support firmware upgrade car-solutions.com

Accessories










screen power cable


DIP code setting

Control type	Dial the code	The screen size	The picture sample
knob	00000000	7/8 inch	The state of the s
	00110000	old 7 inch(There is a missing icon or a line in the middle of the screen after using 7/8 inches)	
	00010000	10.3 inch	
	01000000	7/8 inch	The same of the sa
Large	01100000	12.3 inch	
touchpad	01010000	10.3/12.3 inch (new)	
	10001000	7/8 inch	
Small _ touchpad _	10101000	12.3 inch	
	10011000	10.3/12.3 inch (new)	
	10111000	old 7 inch(There is a missing icon or a line in the middle of the screen after using 7/8 inches)	
mouse	01000000	7/8 inch	
	01100000	12.3 inch	
	01010000	10.3/12.3 inch (new)	
	01110000	old 7 inch(There is a missing icon or a line in the middle of the screen after using 7/8 inches)	
support@c	ar-solutions.com		car-solutions.com

Connection Diagram For Knob:



Connection Diagram For Large Touchpad:




Installtion notes:


- 1. Power off during installation
- 2. Install after all function confirms without error


Screen size	DIP code setting
7/8 inch	01000000
12.3 inch	01100000
10.3/12.3 inch (new model)	01010000


Connection Diagram For Small touchpad or Mouse(method 1):




Connection Diagram For Small touchpad or Mouse(method 2):











Wireless carplay connection

- 1. Turn on WIFI (Fig.1)
- 2. Turn on Bluetooth (Fig.2), and connect Carplay's bluetooth (Fig.3/4)
- 3. After the bluetooth connection is completed, the following prompts will pop up, click 'Allow-Use carplay' (Fig. 5/6)



4. After the connection is successful, the Carplay icon will display on the main menu of the screen (Fig. 7). And it will enter Carplay automatically (Fig. 8)







Wired Android auto connection

- 1. Download Android auto APP on your Android phone (Fig. 1).
- 2. Click 'WireAuto' icon(Fig.2), the prompt 'Please connect your Android device' will pop up(Fig.3).
- 3. Plug your phone to USB port. then it will enter Android auto automatically (Fig. 4).











Wireless Android auto connection

- 1. Turn on WIFI (Fig.1)
- 2. Turn on Bluetooth (Fig.2)
- 3. Search the Android phone's bluetooth on the screen in Carplay system(Fig.3/4/5)
- 4. Pair the bluetooth with your phone. (Fig. 6)
- 5. After connecting the bluetooth, it will pop up the following prompts(Fig.7/8)
- 6. Then it will enter Android auto automatically(Fig.9)





Wireless Airplay connection

- 1. Click 'Airplay' icon first (Fig.1), the pairing information with the phone will be displayed (Fig.2)
- 2. Search wifi signal of Airplay and conenct (Fig. 3/4)
- 3. Turn on Airplay (Fig5/6)
- 4. After connecting Airplay, it will show like Fig.7

Note: If you have connected Carplay before, you need to disconnect Carplay first!





Wired Autolink connection

- 1. Download Android auto APP on your Android phone (Fig. 1).
- 2. Click 'Autolink' icon(Fig.2), the prompt 'Please connect your Android device' will pop up(Fig.3).
- 3. Plug your phone to USB port(Fig.4). then it will enter Android auto automatically(Fig.5).











Original buttons

Button	Function	Operation	Remarks
MENU	System switching	Long press the button for 3 seconds	OEM CarPlay
BACK	Go back	Press the button short time	Apple Car Play Function Google Android Auto
	Restart	Press the button 5 seconds	You can use this function when you get in trouble
Move the pointer Knob Left or Right	Turn the dial Move	Apple Car Play Function	
	Left or Right	Google Android Auto	
Answer/hang up the call	Answer/hang un	Press the button short time	Apple Car Play Function
	the call	Press the button short time	Google Android Auto
(I)		Press the button 3 seconds	Apple Car Play Function
	"Google Assistant"		Google Android Auto


FAQ

- 1.Q: I don't have sound when I connect carplay, what can I do?
 - A:1) Set the AUX output on the original vehicle.
 - 2) Ignore the original car bluetooth instead of just disconnecting.
 - 3) Transfer the fiber cable from the original car to the supplied power plug.
 - 4) Turn up the AUX volume and the media volume.
- 2.Q: I can't connect wireless Carplay automatically, what can I do?
 - A: You can do as following solutions.
 - 1) Please confirm if you turn on wifi and connect carplay's bluetooth.
 - 2) If your car has OEM bluetooth, please delete the connection record, then reconnect carplay's bluetooth.
 - 3) Please confirm the wifi antenna is away from metal.
 - 4) Please confirm all siri permissions are allowed (Fig.1).
 - 5) Reset the connection records on the phone and car (Fig.2) simultaneously, then reconnect.





- 3. Q: The screen will flash, what should I do?
 - A:1) The screen power line is not connected by default, and only connected to the splash screen.
 - 2) The screen power is connected to the wrong position, it should be connected to the box dial code, please see the specific wiring diagram.
 - 3) The connection of the small gray and green wires on the screen power cord and refer to the previous wiring diagram.
- 4.Q: The screen displays a white, black or fuzzy screen, what should I do?
 - A:1) Check whether the LVDS line is connected properly?
- 2) Only transfer the host can line, not the LVDS line. Does the original car screen display normally? If it is normal, the LVDS line is damaged and needs to be replaced.
- 5.Q: When I call someone, he can hear himself, how to do?
 - A: 1) Adjust the volume of the original car to normal use.
 - 2) Turn the volume in 'audio' setting to 13.
 - 3) Turn the 'Microphone Volume' to 12.
 - 4) 'Microphone OP' tune from 0 until no echo is heard.
 - 5) Adjust 'AEC quality' to 2.
 - 6) If the caller hears the echo interval for a long time, fine-tune the 'Microphone delay'.
 - 7) If the caller hears a small voice, you can fine-tune the 'Microphone Volume' and 'Microphone PGA'.



6.Q: The screen is not displayed correctly, the display is not complete, or the icon is missing, what should I do?

A: According to the dial code table of the screen size, try several more dial codes, and each time you change the dial code, you need to power off.

- 7.Q: I install the carplay, but the button on steering wheel can't work.
 - A: Set the setting 'Enable wheel key' to ON(Fig.1)
- 8.Q: The original car has 360 panoramic camera, how should I set it?
- A: 1) Open the CarPlay interface, enter the CarPlay Settings, find the item of reversing, and press OK to enter the reversing option interface.
 - 2) In the reversing option, select the reversing camera option and set it to the original car.
 - 3) The three options of reversing detection line, reversing display track and reversing display radar are set to off.
 - 4) Match the original car reversing option set to high, match 360 display set to off.



9.If the screen flashes after installation, please do the following:

(The last two digits of the power cord label)

15H: Rocker control mode, the default is not connected to this line. When the screen flashes, connect this line, and neither the gray line nor the green line is connected.

17: Knob control mode, the default is not connected to this line. Connect this line when the screen flashes, and the gray line is disconnected and the green line is connected.

19: large touch pad control mode, the default is not connected to this line. Connect this line when the screen flashes, and both the gray line and the green line need to be connected.



Plug the power cord removed from the original car screen

support@car-solutions.com