360° Rotatable Industrial Borescope User Manual



Please read the User Manual carefully before your using!

PREFACE

Thank you for purchasing the new 360° Rotatable Industrial Borescope. In order to use this product safely and correctly, please read this manual thoroughly.

After reading this manual, it is recommended to keep the manual at an easily accessible place, preferably close to the device, for future reference.

LIMITED WARRANTY AND LIABILITY

Uni-Trend guarantees that the product is free from any defect in material and workmanship within one year from the purchase date. This warranty does not apply to damages caused by accident, negligence, misuse, modification, contamination and improper handling. The dealer shall not be entitled to give any other warranty on behalf of Uni-Trend. If you need warranty service within the warranty period, please contact

This warranty is the only compensation you can obtain. Uni-Trend will not be responsible Please charge the device via the home charger (5V=1A, 5V=2A) for any special, indirect, incidental or subsequent damage or loss caused by any reason or speculation. As some areas or countries do not allow limitations on implied warranties and incidental or subsequent damage, the above limitation of liability and stipulation may meets safety rules.

Safety & Maintenance

authorized service center or send the product back with problem description.

not apply to you.

- Do not hit the Lens violently. Do not pull the cables so hard.
- Be careful to use the device in somewhere rough and uneven. and avoid scratching the waterproof layer of probe.
- The Lens probe is not made from heat-resistant materials, so please cool down the temperature of engine to be normal when

Keep the Lens and device clean and dry when not using, to avoid contacting any oil contaminations or other corrosives.


- The product is not suitable for users who are limited in body health, sensory ability or spirit ability.
- Do not let children contact and operate the device.
- Do not disassemble the device randomly and contact sellers for maintenance service if any damaged.
- The product is for industrial borescope use, and not suitable for


medical use or body check.


caused by over-discharge.

- The device is supported to be used in the charging process.
- When the device is not used for a long time, charge it at least once every three months, to avoid unrecoverable damage

Functions









Lens equips a temperature control sensor

Lens alarms in 75°C



card is correct or not.

damage.

Press UP and DOWN button to select the language

Press OK button to save it.

- Enter the Gallery
- Do not violently insert or pull out the TF card to avoid card slot



Press "M" to switch to the Photo-Capturing or Video-Recording

Press "

to capture or record.

Charging Guideline

- 1. Charge the device via the Type-C USB adapter (5V=1A, 5V=2A), and fast charge is not supported.
- 2. 1) In power-on charging, the battery icon shows in green with Press "M" to switch to the Gallery and select the images or videos lightning sign. In power-off charging, the battery icon shows in step by step.

Copy directly via the TF card reader, or connect to computer to

copy via the Type-C cable.

to view. Press " * to delete images or videos.

Images & Videos Copy

transmission, otherwise it will be failed.

- Check the battery status of device, or re-power on the device.
 - Machine crash, image output failed or screen off
 - Press the RESET button on the right side of device, or re-power on

3) Unclear imaging

- The optimum imaging focus is 2cm-10cm, please align the device with the target, or use a clean alcohol cloth to wipe the front-end of In the copy process, please re-power on the device or re-plug the

1) The image output is freezing up

The Lens overheat phenomenon is commonly seen, especially in

Lens overheated

Accessories

the highest LED brightness, but without affecting the normal use or service life.

6) TF card fails to identify

Check whether the TF format is FTA32 or not, not formatting. Please re-insert the TF card when it fails to identify.

	360° Rotatable Industrial Borescope	1
	Type-C Cable	1
	User Manual	1
	Gift Box	1
	Cloth Bag	1
	32GB-TF Card	1

	System Languages	Simplified Chinese, Japanese, English, Korean, French, German, Italian, Spanish, Russian, Polish			
	Image Pixels	JPG:1920*1080			
	Video Pixels	AVI: 1920*1080			
		Photo-capturing, Video-recording, Playback, High temperature warning			
	Basic Functions	protection, Image rotation, Audio recording			
	Storage	Standard 32GB-TF (maximum 64GB)			
Hose	Rotational Angle	180° Bi-directional			
	Hose Material	Medal and hard hose			
	Hose Length	1m	2m	3m	
Lens	Lens Diameter	ns Diameter 8mm			
	Light Sensor Chip	CMOS			
	Field of View (FOV)	70°			
	Depth of Field				
	(DOF)	20~100mm			
	Adjustable LED	4.0-#i 0.1.ED-			
	Lights	4-Setting, 8 LEDs			
	Pixels	Pixels 1000K			
	IP Rating	IP67			
Battery	Battery	3.7V/3000mAh			
	Battery Life	4h			
Working	Lens Temperature	0°C~80°C			
	Working				

The manual is subject to change without prior notice!

Due to different batches, the materials and details of actual products may be slightly different from the graphic information, please refer to the actual product received. Experimental data provided in the page is from internal laboratory of UNI-T, but it should not be a reference for customer to place orders. Any questions, please contact the

UNI-TREND TECHNOLOGY (CHINA) CO., LTD. customer service, thanks!

Long press "U" button for 3s to power on/off.

Lens stops running and screen off in 85°C

1. Press "®" button to enter the Setting page.

The default language is English. The system supports Simplified

Chinese, Japanese, English, Korean, French, German, Italian,

Lens runs normally in 70°C or below

Language Settings

Spanish, Russian and Polish,

Select the Language Setting.

— Card Reader —

Type-C Cable —

Type-C cable when the connection between device and computer

failed. Do not unplug the Type-C cable during the data

charge is not supported.

Please charge the device via the (5V=1A, 5V=2A) charger, and fast

http://www.uni-trend.com

Development Zone, Dongguan City

No.6. Gong Ye Bei 1st Road.

Songshan Lake National High-Tech Industrial

Tel: (86-769) 8572 3888





